

Updating EXBOX.MD

EXBOX.MD firmware updates are performed via Dante Updater (bundled with Dante Controller).

This applies to both EXBOX.MD Version 1 and Version 2 units.

What You Need

Before updating, ensure you have:

- A Windows or macOS computer with the latest version of Dante Controller installed (Dante Updater is included automatically).
- The EXBOX.MD connected to the same Dante network as your computer and powered on.
- A stable network connection – do not disconnect the device or your computer during the update.
- Sufficient time to complete the process without interruption.

How to Proceed

For the complete, step-by-step update procedure, please consult the official resources below:

- [EXBOX.MD User's Manual \(Page 85\)](#)
- [Dante Updater – Official User Guide \(Audinate\)](#)
- [Dante Updater – Video Tutorial](#)



WARNING!

It is strongly recommended to backup the device configuration before running any update.



NOTE

During the update the device will reboot and audio will be interrupted



WARNING!

Do not disconnect the power supply during the update process.
